

VSM - Visual Space Manager

It is important that security personnel know what is happening in the building and where it is happening, at all times. The Visual Space Manager (VSM) module enables the visual surveillance of events (arrivals, departures, alarms, etc.) and the management of alarms and access points in Time&Space system. The application offers a real-time overview of alarms and events in a single module, making it easier for security personnel to manage critical situations. VSM also offers video surveillance system integration¹, adding a new security dimension to any Time&Space system.

Real-time overview

User-friendly interface

Simple setup and management


Surveillance of events and alarms

Video system integration

Graphic event notifications

Real-time surveillance

The operator can monitor all events happening in Time&Space through the main "Live View". They can also set voice and visual event notifications and display floor plans in the desired format. All events – registrations, alarms and notifications – are continuously displayed in a dedicated pane in "Live view":



¹ Provided for a wide range of cameras via integration with Milestone video management software.


Graphic event notifications

An Event Window shows all information for each individual security point and will automatically pop up when an event occurs or on operator selection of that point. The operator can still receive a visual notification of new events while browsing through past events.

Alarm management

VSM enables alarm management. When an alarm occurs, the operator receives a visual notification of the alarm, which can then be acknowledged or deactivated. Authorisations can be set for individual points so that each operator has the appropriate level of access and response authority, while the main administrator has an overview of all alarms. Alarms can be filtered by location, group, status and priority and the following functions are available:


- Enable/Disable alarm
- Acknowledge alarm
- Deactivate alarm
- Show details
- Generate report



Event history

The Event History log enables an overview of the past events and alarms saved in the Time&Space system. The administrator can filter data by event type, date, location, user, reader, alarm, controller or they can search by their own criteria.

The administrator can also view recorded video of those events linked to the video-surveillance system.



Door management


There are always some points in an access control system which need an option for opening manually (visitor access, vehicle barriers, etc.), and there are also times when the programmed options (controller access profiles) need to be overridden. Therefore, VSM enables the operator (depending on their authority) to open and close doors manually and consequently cover all kinds of eventualities.

Video integration

VSM includes a strong integration with Milestone video management system – enabling the viewing of live video for any selected point and the recording of video linked to events and alarms in Time&Space. The operator can access these recordings any time and can then use them to verify occurrences. Video recordings can be connected to individual security events and alarms, simplifying the searching, storing, browsing and forwarding of security incidents.

Milestone products support a wide range of different camera manufacturers, offering openness and flexibility to the system.

Visual Space Manager enables the events recorded in the Time&Space system to be monitored; simply and efficiently.



SPICA

ŠPICA INTERNATIONAL D.O.O.
 POT K SEJMIŠČU 33
 SI - 1231 LJUBLJANA
 SLOVENIA
 T. +386 1 568 08 00
 F. +386 1 568 08 88
 WWW.SPICA.SI
 WWW.SPICA.COM

All specifications are subject to change without prior notice.
 © Spica International 2016.